

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power On	Power Off						
AV								
TEXT								
TV	6CH							
	Sleep							
	Digital							
	RDS							
	Delay							
	Clear	Skip Dwn						
	Direct	Skip Up						
	Stop							
	Pause							
		Dolby						
	Rev	DTS Surr						
	Play	Dts Neo:6						
	Fwd	Logic 7						
	Surr.	Stereo						
		Tuning+						
	Spkr	AM/FM						
		Preset-						
OK	Set							
		Preset+						
MENU								
		Tuning-						
EXIT	CH.							
VOL+	Vol+							
		Night						
CH+								
VOL-	Vol-							
MUTE	Mute	Tone						
CH-								
1	1	AVR						
2	2	DVD						
3	3	CD						
4	4	Tape						
5	5	Vid1/VCR						
6	6	Vid2/TV						
7	7	Vid3/Cbl/S						
8	8							
9	9							
	Tun-M	Dim						
0/10	0							
	Mem	Test						